

Program 6: Vibes

Turn the mod wheel up to approximately 75% for tremolo. Note the settings of the contour generators. If a key is depressed and held down, the contour generators reach the sustain level(zero) and stop all sound, producing a "damped" sound. If a key is tapped and released quickly, the contours "skip" the sustaining setting and move immediately to the long release time, producing a "ringing" vibes sound.

TRIGGER

TRIGGER: MULTI
KB GLIDE: 0

MODULATION

RATE: 44
SHAPE: TRI
TO OSC: OFF
TO FILTER: ON

OSC 1

FOOTAGE: 8'
WAVESHAPE: PW 46
SYNC: OFF

OSC 2

FOOTAGE: 8'
WAVESHAPE: PW 46
INTERVAL: 76

MIXER

OSC 1: 99
NOISE: 0
OSC 2: 38

VOLTAGE CONTROLLED FILTER

KB TRACK: 1/2
CUTOFF: 10
EMPHASIS: 20
CONTOUR AMOUNT: 40

FILTER CONTOUR

ATTACK: 3
DECAY: 56
SUSTAIN: 0
RELEASE: 43

LOUDNESS CONTOUR

ATTACK: 0
DECAY: 67
SUSTAIN: 0
RELEASE: 83